


R. C. Tronics Incorporated

**16573 County Road 38
Goshen, Indiana 46528
Toll Free 1-800-642-8171**

**Phone 1-574-642-3857
Fax 1-574-642-3858
<http://www.rctronics.com>**

RCT 598 LOW VOLTAGE MONITOR / LATCHING



This control is designed to latch to battery negative when voltage level drops below a preset level. It will remain in that condition until power is removed from load.

It is well suited and is often used with RCT-510 or RCT-595 "MANUAL IDLE INCREASER". To install; simply supply +12 VDC power to + VDC, battery negative to - VDC. Then remove battery negative from power solenoid and reconnect wire from that solenoid and connect to the "LOAD" terminal of RCT-598 Low Voltage Monitor / Latching.

DIMENSIONS 1" X 2.4" X 4.3"

Weight 3 OZ.