



- F1 = 22710-00
- F2 = 22710-00
- F3 = 22715-00
- F4 = 22715-00
- F5 = 22715-00
- F6 = 22715-00
- F7 = 22715-00
- F8 = 22720-00
- F9 = 22720-00
- F10 = 22710-00
- F11 = 22710-00
- F12 = 22715-00
- F13 = 22715-00
- F14 = 22720-00
- F15 = 22720-00
- F16 = 22720-00
- F17 = 22720-00
- F18 = 22715-00
- F19 = 22730-00
- F20 = 22730-00
- F21 = 22715-00
- F22 = 22715-00
- F23 = 22715-00
- F24 = 22715-00
- F25 = 22704-00
- F26 = 22715-00
- F27 = 22715-00
- F28 = 22715-00
- F29 = 22715-00
- F30 = 22715-00
- F31 = 22715-00
- F32 = 22725-00
- F33 = 22720-00

- RLY-1 = CB1F-12V
- RLY-2 = CB1F-12V
- RLY-3 = CB1F-12V
- RLY-5 = CB1F-12V
- RLY-10 = CB1F-12V
- RLY-11 = CB1F-12V
- RLY-14 = CB1F-12V
- RLY-15 = CB1F-12V
- RLY-19 = CB1F-12V
- RLY-20 = CB1F-12V
- RLY-21 = CB1F-12V
- RLY-22 = CB1F-12V

ADA Momentary #3 ON & #1 OFF  
 ADA Maintained #3 OFF & #1 ON  
 STOP Momentary #2 ON & #4 OFF  
 STOP Maintained #2 OFF & #4 OFF

Placing D/SW-E  
 "ON" provides  
 constant output  
 at Terminal 28'